



## Savon fait maison au karité, à la vanille et au souci

v15869

Fabriquez du savon avec une base de savon de karité. Vous aurez besoin de 600 g de base de savon pour fabriquer 6 petits pains de savon. Ajoutez de la pâte colorante pour savon, de l'huile essentielle de vanille et du souci séché qui conserve sa couleur dans les pains de savon. Le souci est riche en huiles naturelles connues pour être apaisantes, nettoyantes et bactéricides. N'oubliez pas de placer votre pain de savon dans un porte-savon, en le laissant sécher entre chaque utilisation.

### Comment faire



**1** Pesez la base de savon. Vous aurez besoin de 600 g de base de savon (100 g par pain de savon fini). Nous vous recommandons d'utiliser des gants car la base de savon devient chaude et parce que l'huile essentielle de vanille est très concentrée.



**2** You can melt the soap base either in a water bath or in a microwave when it is cut into 3 x 3 cm chunks. Melt in the microwave at 80% power with 30 second intervals and stir between each interval to prevent heat damage.



**3** Add 2.5 cm yellow soap dye paste, and 18 drops of vanilla essential oil. Stir well.





**4** Wash the mould and spray it with rubbing alcohol. Leave to dry.



**5** Sprinkle a thin layer of dried marigold over the bottom of the mould. Pour the molten soap into the mould.



**6** Remove any air bubbles from the surface by spraying with rubbing alcohol. Remove the bars of soap from the mould once hardened after 2-3 hours.