

Lampenkap met spaghettigaren

v15231

Deze lampenkap is gedecoreerd met spaghettigaren. Gebruik een LED peertje dat niet warm wordt. Benodigde materialen: 100 g spaghettigaren.

Hoe werkt het



Make a small ball of yarn in order to wind the yarn around the lamp shade more easily.



2 Start by securing the end of the yarn with a glue gun onto the inside ring at the top of the lamp shade.



Feed the yarn around the outer ring at the top of the lamp shade and around the bottom ring of the lamp shade.



Now feed the yarn on the inside of the lamp shade and up around the outer ring at the top.



Feed the yarn from the inside around the inside ring at the top. Continue to wind the yarn in this manner until the lamp shade is covered completely. When the ball of yarn is finished, secure the end onto the lamp shade with a glue gun and continue with a new small ball of yarn.



Please note that the outer thread overlaps the inner thread of yarn so that the inner thread is not visible. Finish by attaching the yarn end onto the inside of the shade with a blob of glue.



www.cchobby.be